


# Small engines service manual



**NINTH EDITION**

Covers over 2,000 models

Complete service data for  
all popular engines used on:

- Lawn Mowers
- Compact Tractors
- Karts
- Scooters
- Tillers
- Snowmobiles
- Garden Tillers
- Snow Throwers
- Elevators
- Grinders
- Mixers
- Portable Electric Units
- Portable Pumps
- Power Lawn Rakes

**COVERS**

- |                   |                       |
|-------------------|-----------------------|
| Briggs & Stratton | Lawn Boy              |
| Chrysler          | McCulloch             |
| Clinton           | O&R                   |
| Cox               | (Ohlsson & Rice)      |
| Craftsman         | Onan                  |
| Eska              | Pincor                |
| Homelite          | (Pioneer Gen-E-Motor) |
| Honda             | Power Products        |
| Iron Horse        | Reo                   |
| Jacobsen          | Tecumseh              |
| Kohler            | Toro                  |
| Lauson            | West Bend             |
|                   | Wisconsin             |

More than 800  
Over 40,000 Models!  
New Fundamentals Section!



36



# Small Engines Service Manual

(Ninth Edition)

Only engines of less than 45 cubic inch displacement are contained in this manual.

## CONTENTS



### GENERAL

Engine Fundamentals .....	3	Ignition System Service.....	22
Carburetor Fundamentals .....	5	Carburetor Service .....	26
Ignition System Fundamentals.....	9	Engine Service .....	27
Engine Power and Torque.....	17	Track Tuning .....	31
Trouble Shooting .....	19	Service Tool Guide.....	32

### ENGINE SHOP MANUALS

Briggs & Stratton .....	35, 44, 55, 69, 74	Lawn Boy .....	213
Chrysler .....	76, 78	McCulloch .....	225, 232
Clinton .....	83, 84, 91, 95, 102, 110, 114, 119, 126	O&R .....	237
Cox .....	129	Onan .....	244, 250, 253, 258
Craftsman .....	131	Pincor .....	263
Eska .....	137	Power Products .....	(See Tecumseh)
Homelite .....	138, 143, 150, 156, 163	Reo .....	268
Honda .....	169, 172, 176, 180	Tecumseh .....	269, 272, 279, 285, 289, 299, 304
Iron Horse .....	(See Lawn Boy)	Toro .....	311
Jacobsen .....	184, 186	West Bend .....	(See Chrysler)
Kohler .....	195, 198, 208	Wisconsin .....	312, 314, 319, 323
Lauson .....	(See Tecumseh)		



Published by TECHNICAL PUBLICATIONS DIV.

INTERTEC PUBLISHING CORP.

1014 Wyandotte Street

Kansas City, Missouri 64105


a subsidiary of HOWARD W. SAMS & CO., INC.



Printed in U.S.A.

CKO  
CO8  
IPC  
C. 4

COPYRIGHT 1969 BY INTERTEC PUBLISHING CORP., KANSAS CITY, MISSOURI





# FUNDAMENTALS SECTION

## ENGINE FUNDAMENTALS

### OPERATING PRINCIPLES

The small engines used to power lawn mowers, garden tractors and many other items of power equipment in use today are basically similar. All are technically known as "Internal Combustion Reciprocating Engines."

The source of power is heat formed by the burning of a combustible mixture of petroleum products and air. In a reciprocating engine, this burning takes place in a closed cylinder containing a piston. Expansion resulting from the heat of combustion applies pressure on the piston to turn a shaft by means of a crank and connecting rod.

The fuel-air mixture may be ignited by means of an electric spark (Otto Cycle Engine) or by heat formed from compression of air in the engine cylinder (Diesel Cycle Engine). The complete series of events which must take place in order for the engine to run may occur in one revolution of the crankshaft (two strokes of the piston in cylinder) which is referred to as a "Two-Stroke Cycle Engine," or in two revolutions of the crankshaft (four strokes of the piston in cylinder) which is referred to as a "Four-Stroke Cycle Engine."

**OTTO CYCLE.** In a spark ignited engine, a series of five events is required in order for the engine to provide power. This series of events is called the "Cycle" (or "Work Cycle") and is repeated in each cylinder of the engine as long as work is being done. This series of events which comprise the "Cycle" is as follows:

1. The mixture of fuel and air is pushed into the cylinder by atmospheric pressure when the pressure within the engine cylinder is reduced by the piston moving downward in the cylinder (or by applying pressure to the fuel-air mixture as by crankcase compression in the crankcase of a "Two-Stroke Cycle Engine" which is described in a later paragraph).

2. The mixture of fuel and air is compressed by the piston moving upward in the cylinder.

3. The compressed fuel-air mixture is ignited by a timed electric spark.

4. The burning fuel-air mixture expands, forcing the piston downward in the cylinder thus converting the chemical energy generated by combustion into mechanical power.

5. The gaseous products formed by the burned fuel-air mixture are exhausted from the cylinder so that a new "Cycle" can begin.

The above described five events which comprise the work cycle of an engine are commonly referred to as (1), INTAKE; (2), COMPRESSION; (3), IGNITION; (4), EXPANSION (POWER); and (5), EXHAUST.

**DIESEL CYCLE.** The Diesel Cycle differs from the Otto Cycle in that air alone is drawn into the cylinder during the intake period. The air is heated from being compressed by the piston moving upward in the cylinder, then a finely atomized charge of fuel is injected into the cylinder where it mixes with the air and is ignited by the heat of the compressed air. In order to create sufficient heat to ignite the injected fuel, an engine operating on the Diesel Cycle must compress the air to a much greater degree than an engine operating on the Otto Cycle where the fuel-air mixture is ignited by an electric spark. The power and exhaust events of the Diesel Cycle are similar to the power and exhaust events of the Otto Cycle.

### TWO-STROKE CYCLE ENGINES.

Two stroke cycle engines may be of the Otto Cycle (spark ignition) or Diesel Cycle (compression ignition) type. However, since the two-stroke cycle engines listed in the repair section of this manual are all of the Otto Cycle type, operation of two-stroke Diesel Cycle engines will not be discussed in this section.




Fig. 1-1—Schematic diagram of a two-stroke cycle engine operating on the Otto Cycle (spark ignition). View "B" shows piston near top of upward stroke and atmospheric pressure is forcing air through carburetor (C), where fuel is mixed with the air, and the fuel-air mixture enters crankcase through open reed valve (R). In view "A", piston is near bottom of downward stroke and has opened the cylinder exhaust and intake ports; fuel-air mixture in crankcase has been compressed by downward stroke of engine and flows into cylinder through open port. Incoming mixture helps clean burned exhaust gases from cylinder.

In two-stroke cycle engines, the piston is used as a sliding valve for the cylinder intake and exhaust ports. The intake and exhaust ports are both open when the piston is at the bottom of its downward stroke (bottom dead center or "B.D.C."). The exhaust port is open to atmospheric pressure; therefore, the fuel-air mixture must be elevated to a higher than atmospheric pressure in order for the mixture to enter the cylinder. As the crankshaft is turned from B.D.C. and the piston starts on its upward stroke, the intake and exhaust ports are closed and the fuel-air mixture in the cylinder is compressed. When the piston is at or near the top of its upward stroke (top dead center or "T.D.C."), an electric spark across the electrode gap of the spark plug ignites the fuel air mixture. As the crankshaft turns past T.D.C. and






Fig. 1-2—Schematic diagram of two-stroke cycle engine operating on Otto Cycle. Engine differs from that shown in Fig. 1-1 in that piston is utilized as a sliding valve to open and close intake (carburetor to crankcase) port (IP) instead of using reed valve (R—Fig. 1-1).

C. Carburetor  
EX. Exhaust port  
IP. Intake port  
(carburetor to  
crankcase)

TP. Transfer port  
(crankcase to  
cylinder)




Fig. 1-3—Schematic diagram of two-stroke cycle engine similar to those shown in Figs. 1-1 and 1-2 except that a rotary carburetor to crankcase port valve is used. Disc driven by crankshaft has rotating opening (RO) which uncovers stationary opening (SO) in crankcase when piston is on upward stroke. Carburetor is (C).

the piston starts on its downward stroke, the rapidly burning fuel-air mixture expands and forces the piston downward. As the piston nears bottom of its downward stroke, the cylinder exhaust port is opened and the burned gaseous products from combustion of the fuel-air mixture flows out the open port. Slightly further downward travel of the piston opens the cylinder intake port and a fresh charge of fuel-air mixture is forced into the cylinder. Since the exhaust port remains open, the incoming flow of fuel-air mixture helps clean (scavenge) any remaining burned gaseous products from the cylinder. As the crankshaft turns past B.D.C. and the piston starts on its upward stroke, the cylinder intake and exhaust ports are closed and a new cycle begins.

Since the fuel-air mixture must be elevated to a higher than atmospheric pressure to enter the cylinder of a two-stroke cycle engine, a compressor pump must be used. Coincidentally, downward movement of the piston decreases the volume of the engine crankcase. Thus, a compressor pump is made available by sealing the engine crankcase and connecting the carburetor to a port in the crankcase. When the piston moves upward, volume of the crankcase is increased which lowers pressure within the crankcase to below atmospheric. Air will then be forced through the carburetor, where fuel is mixed with the

air, and on into the engine crankcase. In order for downward movement of the piston to compress the fuel-air mixture in the crankcase, a valve must be provided to close the carburetor to crankcase port. Three different types of valves are used. In Fig. 1-1, a reed type inlet valve is shown in the schematic diagram of the two-stroke cycle engine. Spring steel reeds (R) are forced open by atmospheric pressure as shown in view "B" when the piston is on its upward stroke and pressure in the crankcase is below atmospheric. When the piston reaches T.D.C., the reeds close as shown in view "A" and fuel-air mixture is trapped in the crankcase to be compressed by downward movement of the piston. In Fig. 1-2, a schematic diagram of a two-stroke cycle engine is shown in which the piston is utilized as a sliding carburetor-crankcase port (third port) valve. In Fig. 1-3, a schematic diagram of a two-stroke cycle engine is shown in which a slotted disc (rotary valve) attached to the engine crankshaft opens the carburetor-crankcase port when the piston is on its upward stroke. In each of the three basic designs shown, a transfer port (TP—Fig. 1-2) connects the crankcase compression chamber to the cylinder; the transfer port is the cylinder intake port through which the compressed fuel-air mixture in the crankcase is transferred to the cylinder when the piston is at bottom of stroke as shown in view "A."

Due to rapid movement of the fuel-air mixture through the crankcase, the crankcase cannot be used as a lubricating oil sump because the oil would be carried into the cylinder. Lubrication is accomplished by mixing a small amount of oil with the fuel; thus, lubricating oil for the engine moving parts is carried into the crankcase with the fuel-air mixture. Normal lubricating oil to fuel mixture ratios vary from one part of oil mixed with 16 to 20 parts of fuel by volume. In all instances, manufacturer's recommendations for fuel-oil mixture ratio should be observed.

**FOUR-STROKE CYCLE.** In a four-stroke cycle engine operating on the Otto Cycle (spark ignition), the five events of the cycle take place in four strokes of the piston, or in two revolutions of the engine crankshaft. Thus, a power stroke occurs only on alternate downward strokes of the piston.


In view "A" of Fig. 1-4, the piston is on the first downward stroke of the cycle. The mechanically operated intake valve has opened the intake port and, as the downward movement of the piston has reduced the air pressure in the cylinder to below atmospheric pressure, air is forced through the carburetor, where fuel is mixed with the air, and into the cylinder through the open intake port. The intake valve remains open and the fuel-air mixture continues to flow into the cylinder until the piston reaches the bottom of its downward stroke. As the piston starts on its first upward stroke, the mechanically operated intake valve closes and, since the exhaust valve is closed, the fuel-air mixture is compressed as in view "B."

Just before the piston reaches the top of its first upward stroke, a spark at the spark plug electrodes ignites the compressed fuel-air mixture. As the engine crankshaft turns past top center, the burning fuel-air mixture expands rapidly and forces the piston downward on its power stroke as shown in view "C." As the piston reaches the bottom of the power stroke, the mechanically operated exhaust valve starts to open and as the pressure of the burned fuel-air mixture is higher than atmospheric pressure, it starts to flow out the open exhaust port. As the engine crankshaft turns past bottom center, the exhaust valve is almost completely open and remains open during the up-



ward stroke of the piston as shown in view "D." Upward movement of the piston pushes the remaining burned fuel-air mixture out of the exhaust port. Just before the piston reaches the top of its second upward or exhaust stroke, the intake valve opens and the exhaust valve closes. The cycle is completed as the crankshaft turns past top center and a new cycle begins as the piston starts downward as shown in view "A."

In a four-stroke cycle engine operating on the Diesel Cycle, the sequence of events of the cycle is similar to that described for operation on the Otto Cycle, but with the following exceptions: On the intake stroke, air only is taken into the cylinder. On the compression stroke, the air is highly compressed which raises the temperature of the air. Just before the piston reaches top dead center, fuel is injected into the cylinder and is ignited by the heated, compressed air. The remainder of the cycle is similar to that of the Otto Cycle.



**Fig. 1-4—Schematic diagram of four-stroke cycle engine operating on the Otto (spark ignition) cycle. In view "A", piston is on first downward (intake) stroke and atmospheric pressure is forcing fuel-air mixture from carburetor into cylinder through the open intake valve. In view "B", both valves are closed and piston is on its first upward stroke compressing the fuel-air mixture in cylinder. In view "C", spark across electrodes of spark plug has ignited fuel-air mixture and heat of combustion rapidly expands the burning gaseous mixture forcing the piston on its second downward (expansion or power) stroke. In view "D", exhaust valve is open and piston on its second upward (exhaust) stroke forces the burned mixture from cylinder. A new cycle then starts as in view "A".**

## CARBURETOR FUNDAMENTALS

### OPERATING PRINCIPLES

Function of the carburetor on a spark-ignition engine is to atomize the fuel and mix the atomized fuel in proper proportions with air flowing to the engine intake port or intake manifold. Carburetors used on engines that are to be operated at constant speeds and under even loads are of simple design since they only have to mix fuel and air in a relatively constant ratio. On engines operating at varying speeds and loads, the carburetors must be more complex because different fuel-air mixtures are required to meet the varying demands of the engine.


**FUEL-AIR MIXTURE RATIO REQUIREMENTS.** To meet the demands of an engine being operated at varying speeds and loads, the carburetor must mix fuel and air at different mixture ratios. Fuel-air mixture ratios required for different operating conditions are approximately as follows:

	Fuel	Air
Starting, cold weather ...	1 lb.	7 lbs.
Accelerating .....	1 lb.	9 lbs.
Idling (no load) .....	1 lb.	11 lbs.
Part open throttle .....	1 lb.	15 lbs.
Full load, open throttle ..	1 lb.	13 lbs.

**BASIC DESIGN.** Carburetor design is based on the venturi principle which simply means that a gas or liquid flowing through a necked-down section (venturi) in a passage undergoes an increase in velocity (speed) and a decrease in pressure as compared to the velocity and pressure in full size sections of the passage. The principle is illustrated in Fig. 2-1, which shows air passing through a carburetor venturi. The figures given for air speeds and vacuum are approximate for a typical wide-open throttle operating condition. Due to low pressure (high vacuum) in the venturi, fuel is forced out through the fuel nozzle by the atmospheric pressure (0 vacuum) on the fuel; as fuel is emitted from the nozzle, it is atomized by the high velocity air flow and mixes with the air.

In Fig. 2-2, the carburetor choke plate and throttle plate are shown in relation to the venturi. Downward pointing arrows indicate air flow through the carburetor.

At cranking speeds, air flows through the carburetor venturi at a slow speed; thus, the pressure in the venturi does not usually decrease to the extent that atmospheric pressure



**Fig. 2-1—Drawing illustrating the venturi principle upon which carburetor design is based. Figures at left are inches of mercury vacuum and those at right are air speeds in feet per second that are typical of conditions found in a carburetor operating at wide open throttle. Zero vacuum in fuel nozzle corresponds to atmospheric pressure.**

on the fuel will force fuel from the nozzle. If the choke plate is closed as shown by dotted line in Fig. 2-2, air cannot enter into the carburetor and pressure in the carburetor decreases






Fig. 2-2 — Drawing showing basic carburetor design. Text explains operation of the choke and throttle valves. In some carburetors, a primer pump may be used instead of the choke valve to provide fuel for the starting fuel-air mixture.

greatly as the engine is turned at cranking speed. Fuel can then flow from the fuel nozzle. In manufacturing the carburetor choke plate or disc, a small hole or notch is cut in the plate so that some air can flow through the plate when it is in closed position to provide air for the starting fuel-air mixture. In some instances after starting a cold engine, it is advantageous to leave the choke plate in a partly closed position as the restriction of air flow will decrease the air pressure in carburetor venturi, thus causing more fuel to flow from the nozzle resulting in a richer fuel-air mixture. The choke plate or disc should be in fully open position for normal engine operation.

If, after the engine has been started, the throttle plate is in the wide-open position as shown by the solid line in Fig. 2-2, the engine can obtain enough fuel and air to run at dangerously high speeds. Thus, the throttle plate or disc must be partly closed as shown by the dotted lines to control engine speed. At no load, the engine requires very little air and fuel to run at its rated speed and the throttle must be moved on toward the closed position as shown by the dash lines. As more load is placed on the

engine, more fuel and air are required for the engine to operate at its rated speed and the throttle must be moved closer to the wide open position as shown by the solid line. When the engine is required to develop maximum power or speed, the throttle must be in the wide open position.

Although some carburetors may be as simple as the basic design just described, most engines require more complex design features to provide variable fuel-air mixture ratios for different operating conditions. These design features will be described in the following paragraphs which outline the different carburetor types.

**CARBURETOR TYPES**

Carburetors used on small engines are usually classified by types as to method of delivery of fuel to the carburetor fuel nozzle. The following paragraphs describe the features and operating principles of the different type carburetors from the most simple suction lift type to the more complex float and diaphragm types.

**SUCTION LIFT CARBURETOR.** A cross-sectional drawing of a typical suction lift carburetor is shown in Fig. 2-4. Due to the low pressure at the orifice (O) of the fuel nozzle and to atmospheric pressure on the fuel in fuel supply tank, fuel is forced up through the fuel pipe and out of the nozzle into the carburetor venturi where it is mixed with the air flowing through the venturi. A check ball is located in the lower end of the fuel pipe to prevent pulsations of air pressure in the venturi from forcing fuel back down through the fuel pipe. The lower end of the fuel pipe has a fine mesh screen to prevent foreign




Fig. 2-4—Principle of suction lift carburetor is illustrated in above drawing. Atmospheric pressure on fuel forces fuel up through pipe and out nozzle orifice (O). Needle (N) is used to adjust amount of fuel flowing from nozzle to provide correct fuel-air mixture for engine operation. Choke (C) and throttle (T) valves are shown in wide open position.

material or dirt in fuel from entering the fuel nozzle. Fuel-air ratio can be adjusted by opening or closing the adjusting needle (N) slightly; turning the needle in will decrease flow of fuel out of nozzle orifice (O).

In Fig. 2-3, a cut-away view is shown of a suction type carburetor used on several models of a popular make small engine. This carburetor features an idle fuel passage, jet and adjustment screw. When carburetor throttle is nearly closed (engine is at





Fig. 2-3—Cut-away drawing of a suction lift carburetor used on one well known make engine. Ball in stand pipe prevents fuel in carburetor from flowing back into fuel tank.



low idle speed), air pressure is low (vacuum is high) at inner side of throttle plate. Therefore, atmospheric pressure in fuel tank will force fuel through the idle jet and adjusting screw orifice where it is emitted into the carburetor throat and mixes with air passing the throttle plate. The adjustment screw is turned in or out until an optimum fuel-air mixture is obtained and engine runs smoothly at idle speed. When the throttle is opened to increase engine speed, air velocity through the venturi increases, air pressure in the venturi decreases and fuel is emitted from the nozzle. Power adjustment screw (high speed fuel needle) is turned in or out to obtain proper fuel-air mixture for engine running under operating speed and load.


**FLOAT TYPE CARBURETOR.** The principle of float type carburetor operation is illustrated in Fig. 2-5. Fuel is delivered at inlet (I) by gravity with fuel tank placed above carburetor, or by a fuel lift pump when tank is located below carburetor inlet. Fuel flows into the open inlet valve (V) until fuel level (L) in bowl lifts float against fuel valve needle and closes the valve. As fuel is emitted from the nozzle (N) when engine is running, fuel level will drop, lowering the float and allowing valve to open so that fuel will enter the carburetor to meet the requirements of the engine.



**Fig. 2-5—Drawing showing basic float type carburetor design. Fuel must be delivered under pressure either by gravity or by use of fuel pump, to the carburetor fuel inlet (I). Fuel level (L) operates float (F) to open and close inlet valve (V) to control amount of fuel entering carburetor. Also shown are the fuel nozzle (N), throttle (T) and choke (C).**

**Fig. 2-6—Cross-sectional drawing of float type carburetor used on a popular small engine.**

0. Orifice
1. Main fuel needle
2. Packing
3. Packing nut
4. Carburetor bowl
5. Float tang
6. Float hinge pin
7. Gasket
8. Inlet valve
9. Fuel inlet
10. Carburetor body
11. Inlet valve seat
12. Vent
13. Choke plate
14. Idle orifice
15. Idle fuel needle
16. Plug
17. Gasket
18. Venturi
19. Float
20. Fuel bowl vent
21. Choke
22. Fuel nozzle




In Fig. 2-6, a cut-away view of a well known make of small engine float type carburetor is shown. Atmospheric pressure is maintained in fuel bowl through passage (20) which opens into carburetor air horn ahead of the choke plate (21). Fuel level is maintained at just below level of opening (O) in nozzle (22) by float (19) actuating inlet valve needle (8). Float height can be adjusted by bending float tang (5).

When starting a cold engine, it is necessary to close the choke plate (21) as shown by dotted lines so as to lower the air pressure in carburetor venturi (18) as engine is cranked. Then, fuel will flow up through nozzle (22) and will be emitted from openings (O) in nozzle. When an engine is hot, it will start on a leaner fuel-air mixture than when cold and may start without the choke plate being closed.

When engine is running at slow idle speed (throttle plate nearly closed as indicated by dotted lines in Fig. 2-6), air pressure above the throttle plate is low and atmospheric pressure in fuel bowl forces fuel up through the nozzle and out through orifice in seat (14) where it mixes with air passing the throttle plate. The idle fuel mixture is adjustable by turning needle (15) in or out as required. Idle speed is adjustable by turning the throttle stop screw (not shown) in or out to control amount of air passing the throttle plate.

When throttle plate is opened to increase engine speed, velocity of air flow through venturi (18) increases, air pressure at venturi decreases and



**Fig. 2-7—Illustration of air bleed principle explained in text.**

fuel will flow from openings (O) in nozzle instead of through orifice in idle seat (14). When engine is running at high speed, pressure in nozzle (22) is less than at vent (12) opening in carburetor throat above venturi. Thus, air will enter vent and travel down the vent into the nozzle and mix with the fuel in the nozzle. This is referred to as air bleeding and is illustrated in Fig. 2-7.

Many different designs of float type carburetors will be found when servicing the different makes and models of small engines. Reference should be made to the engine repair section of this manual for adjustment and overhaul specifications. Refer to carburetor servicing paragraphs in fundamentals sections for service hints.







# IGNITION SYSTEM FUNDAMENTALS

The ignition system provides a properly timed surge of extremely high voltage electrical energy which flows across the spark plug electrode gap to create the ignition spark. Small engines may be equipped with either a magneto or battery ignition system. A magneto ignition system generates electrical energy, intensifies (transforms) this electrical energy to the extremely high voltage required and delivers this electrical energy at the proper time for the ignition spark. In a battery ignition system, a storage battery is used as a source of electrical energy and the system transforms the relatively low electrical voltage from the battery into the high voltage required and delivers the high voltage at proper time for the ignition spark. Thus, the function of the two systems is somewhat similar except for the basic source of electrical energy. The fundamental operating principles of ignition systems are explained in the following paragraphs.

## MAGNETISM AND ELECTRICITY

The fundamental principles upon which ignition systems are designed are presented in this section. As the study of magnetism and electricity is an entire scientific field, it is beyond the scope of this manual to fully explore these subjects. However, the following information will impart a working knowledge of basic principles which should be of value in servicing small engines.

**MAGNETISM.** The effects of magnetism can be shown easily while the theory of magnetism is too complex to be presented here. The effects of magnetism were discovered many years ago when fragments of iron ore were found to attract each other and also attract other pieces of iron. Further, it was found that when suspended in air, one end of the iron ore fragment would always point in the direction of the North Star. The end of the iron ore fragment pointing north was called the "north pole" and the opposite end the "south pole." By stroking a piece of steel with a "natural magnet," as these iron ore fragments were called, it was found




Fig. 3-1 — In left view, field of force of permanent magnet is illustrated by arrows showing direction of magnetic force from north pole (N) to south pole (S). In center view, lines of magnetic force are being attracted by soft iron bar that is being moved into the magnetic field. In right view, the soft iron bar has been moved close to the magnet and the field of magnetic force is concentrated within the bar.

that the magnetic properties of the natural magnet could be transferred or "induced" into the steel.

Steel which will retain magnetic properties for an extended period of time after being subjected to a strong magnetic field are called "permanent magnets;" iron or steel that loses such magnetic properties soon after being subjected to a magnetic field are called "temporary magnets." Soft iron will lose magnetic properties almost immediately after being removed from a magnetic field, and so is used where this property is desirable.

The area affected by a magnet is called a "field of force." The extent of this field of force is related to the strength of the magnet and can be determined by use of a compass. In practice, it is common to illustrate the field of force surrounding a magnet by lines as shown in Fig. 3-1 and the field of force is usually called "lines of force" or "flux." Actually, there are no "lines;" however, this is a convenient method of illustrating the presence of the invisible magnetic forces and if a certain magnetic force is defined as a "line of force," then all magnetic forces may be measured by comparison. The number of "lines of force" making up a strong magnetic field is enormous.

Most materials when placed in a magnetic field are not attracted by the magnet, do not change the magnitude or direction of the magnetic

field, and so are called "non-magnetic materials." Materials such as iron, cobalt, nickel or their alloys, when placed in a magnetic field will concentrate the field of force and hence are magnetic conductors or "magnetic materials." There are no materials known in which magnetic fields will not penetrate and magnetic lines of force can be deflected only by magnetic materials or by another magnetic field.

Alnico, an alloy containing aluminum, nickel and cobalt, retains magnetic properties for a very long period of time after being subjected to a strong magnetic field and is extensively used as a permanent magnet. Soft iron, which loses magnetic properties quickly, is used to concentrate magnetic fields as in Fig. 3-1.

**ELECTRICITY.** Electricity, like magnetism, is an invisible physical force whose effects may be more readily explained than the theory of what electricity consists of. All of us are familiar with the property of electricity to produce light, heat and mechanical power. What must be explained for the purpose of understanding ignition system operation is the inter-relationship of magnetism and electricity and how the ignition spark is produced.

Electrical current may be defined as a flow of energy in a conductor which, in some ways, may be com-



Bạn đang có trong tay thông tin cơ bản của một trong số những tài liệu có hàm lượng chất xám cao, với những thông tin vô cùng hữu ích cho quá trình học tập và nghiên cứu của bản thân bạn !

Bạn đã và đang trải qua những ưu tư, trăn trở của bản thân mình trước biển kiến thức mênh mông vô hạn và đang tìm hướng đi cho riêng mình bằng việc biến kiến thức thành tài sản tri thức của riêng bạn !

*Hãy để Thư viện trường Đại học Sư phạm Kỹ thuật Tp. HCM chia sẻ những khó khăn và trăn trở đó cùng bạn!*

*Hãy đến với Thư viện trường Đại học Sư phạm Kỹ thuật Tp. HCM để cùng nhau, chúng ta xây dựng vương quốc khoa học và trí tuệ của chính mình !*

*Cùng với bạn, Thư viện ĐH Sư phạm Kỹ thuật Tp. HCM mong ước góp phần duy trì và phát triển văn hóa đọc !*



**Hãy đến với chúng tôi - Thư viện trường Đại học Sư phạm Kỹ thuật Tp. HCM để cảm nhận, trải nghiệm và biến ước mơ khoa học của bạn thành hiện thực !**

Hân hạnh được đón tiếp và phục vụ bạn tại  
**Số 1 – 3, Võ Văn Ngân, Phường Linh Chiểu, Quận Thủ Đức, Tp. HCM**  
ĐT: (08) 3896 9920 – Email: [thuvienspkt@hcmute.edu.vn](mailto:thuvienspkt@hcmute.edu.vn)  
<http://www.thuvienspkt.edu.vn> – <http://thuvien.hcmute.edu.vn>



***Thông tin tài trợ!***



A series of horizontal dotted lines spanning the width of the page, intended for writing the donor information.





**B**ạn đang có trong tay thông tin cơ bản của một trong số những tài liệu có hàm lượng chất xám cao, với những thông tin vô cùng hữu ích cho quá trình học tập và nghiên cứu của bản thân bạn !

Bạn đã và đang trải qua những ưu tư, trăn trở của bản thân mình trước biển kiến thức mênh mông vô hạn và đang tìm hướng đi cho riêng mình bằng việc biến kiến thức thành tài sản tri thức của riêng bạn !

*Hãy để Thư viện trường Đại học Sư phạm Kỹ thuật Tp. HCM chia sẻ những khó khăn và trăn trở đó cùng bạn!*

*Hãy đến với Thư viện trường Đại học Sư phạm Kỹ thuật Tp. HCM để cùng nhau, chúng ta xây dựng vương quốc khoa học và trí tuệ của chính mình !*

*Cùng với bạn, Thư viện ĐH Sư phạm Kỹ thuật Tp. HCM mong ước góp phần duy trì và phát triển văn hóa đọc !*



**Hãy đến với chúng tôi - Thư viện trường Đại học Sư phạm Kỹ thuật Tp. HCM** để cảm nhận, trải nghiệm và biến ước mơ khoa học của bạn thành hiện thực !

Hân hạnh được đón tiếp và phục vụ bạn tại  
**Số 1 – 3, Võ Văn Ngân, Phường Linh Chiểu, Quận Thủ Đức, Tp. HCM**  
ĐT: (08) 3896 9920 – Email: [thuvienspkt@hcmute.edu.vn](mailto:thuvienspkt@hcmute.edu.vn)  
<http://www.thuvienspkt.edu.vn> – <http://thuvien.hcmute.edu.vn>



***Thông tin tài trợ!***



A series of horizontal dotted lines arranged in a column, providing a space for writing. The lines are evenly spaced and extend across the width of the page, framed by decorative elements on the left and right sides.

